



8IRBLAL

INSTALLATION DETAILS:

1. Drill Dia. 3/4" [19 mm] hole within 6" - 8" from the faucet hole and install Suspended Spray Assembly (1) into it. Mount Washer (2) from underneath and secure the assembly by tightening Nut (3) using a 22 mm wrench. Use the second Nut (3) to lock the first one.
2. Connect Spray Flex Hose (4) to the spray assembly as shown and install Spring (5). Attach Hand Held Spray (6) to the free end of the spray flex hose. Install the spray into Spray Holder (7) as shown.
3. Slide free ends of the flex hoses attached to Faucet Assembly (8) thru the faucet hole. Secure the faucet from underneath using Mounting Kit (9).
4. Connect the faucet and suspended spray assembly using Flex Hose (10) with attached Adapter (11). Tighten the end with attached adapter first.
5. Connect Supply Flex Hoses (12) to the water supply lines : left to the hot, right - to the cold.
6. Tighten Set-Screw (1.1) using 2.5 mm Allen key (supplied) to fix Spray Holder (7) in the desired position.

9/25/2009